



Elite 1500 Plug 'n' Play Adaptor Harness HT-140921

Supported Models

MX-5 MAZDASPEED SPECIAL EDITION (FACTORY TURBO)
MX-5 NB 1.8 VCT (2000-2004)
MX-5 NB 1.8 NON-VCT (2000-2004)

Package Contents

THIS MAZDA MX-5 PACKAGE CONTAINS THE FOLLOWING:

- MAZDA MX-5 ELITE 1500 PLUG 'N' PLAY ADAPTOR (HT-140921)
- ELITE SERIES PLUG 'N' PLAY ADAPTOR HARNESS (HT-130201)
- INTAKE AIR TEMPERATURE SENSOR (HT-010200)



Application Notes

THIS MAZDA MX-5 SPECIAL EDITION (FACTORY TURBO), VCT, NON-VCT ELITE 1500 PLUG 'N' PLAY ADAPTOR HARNESS IS SUITABLE FOR USE WITH A HALTECH ELITE 1500 ECU ONLY.

ENSURE THAT THE CORRECT BASEMAP IS LOADED BEFORE STARTING THE VEHICLE.

THE BASEMAP IS ONLY FOR USE AS A STARTING POINT AND THE ECU WILL REQUIRE APPROPRIATE TUNING.

HALTECH WILL NOT BE HELD RESPONSIBLE FOR ENGINE DAMAGE DUE TO THE IMPROPER USE OF BASEMAPS.

THE 16 PIN AUXILIARY CONNECTOR PROVIDES A NUMBER OF ADDITIONAL INPUT/OUTPUT LINKS TO THE HALTECH ELITE ECU. THIS KIT IS SUPPLIED WITH SPARE PINS FOR USE WITH THE 16 PIN AUXILIARY CONNECTOR.

AN APPROPRIATE CRIMPING TOOL IS RECOMMENDED TO USE THE 16 PIN AUXILIARY CONNECTOR.

A CRIMPING TOOL KIT (PART # HT-070300) CAN BE PURCHASED AT WWW.HALTECH.COM

AFTER THE INSTALLATION OF THIS PLUG 'N' PLAY KIT, FACTORY PANELS MAY BE RE-INSTALLED.

Elite Basemaps

MAKE	MODEL	CODE	ENGINE	BASEMAP
MAZDA	MX-5 SPECIAL EDITION (FACTORY TURBO)	NB	BP-4W	HT-140921 EXXXX Mazda MX5 NB SE Turbo
MAZDA	MX-5 1.8 VCT (00-04)	NB	BP-Z3	HT-140921 EXXXX Mazda MX5 NB VCT
MAZDA	MX-5 1.8 NON-VCT (00-04)	NB	BP-4W	HT-140921 EXXXX Mazda MX5 NB Non-VCT

NOTE: "EXXXX" IN THE BASEMAP FILE NAME DENOTES WHICH ECU MODEL THAT THE BASEMAP SUPPORTS. E.G "HT-140921 E1000 Mazda MX5 NB VCT.e1000" IS THE BASEMAP CREATED FOR USE WITH AN ELITE 1000 ECU.

Jumper ID Settings

THIS MX-5 PLUG 'N' PLAY ADAPTOR HARNESS IS PRE-CONFIGURED FOR USE WITH AN ELITE 1500 ECU, HOWEVER, THE JUMPERS ON BOARD CAN PROVIDE CAPABILITY WITH OTHER ECUS, INDICATED BELOW WITH (Elite 750-2500).



Jumper	Connection	Jumper	Connection
A	Connects Check Engine Light to Injector Output 5 (Elite 750)	I	Supplies VCT Solenoid (+) with +12V
B	Connects Check Engine Light to Stepper 1 (Elite 1000-2500)	J	Connects Wastegate Solenoid to Wastegate Control Monitor
C	Connects Alternator Control to Ignition Output 6 (Elite 750)	K	Connects VCT Solenoid Control to Injector Output 6 (Elite 750)
D	Connects Alternator Control to Stepper 4 (Elite 1000-2500)	L	Connects VCT Solenoid Control to Stepper 3 (Elite 1000-2500)
E	Connects Wastegate Solenoid to Ignition Output 5 (Elite 750)	M	Connects A/C Request to a 1k Pulldown
F	Connects Wastegate Solenoid to Stepper 2 (Elite 1000-2500)	N	Connects Mass Air Flow Sensor to a 1k Pulldown
G	Connects ECR Relay to the on-board ECR Circuit (Elite 750)	O	Use when Alternator Control circuit requires +5V Signal
H	Connects ECR Relay to DPO 6 (Elite 1000-2500)	P	Use when Alternator Control circuit requires +12V Signal

THIS MX-5 PLUG 'N' PLAY ADAPTOR HARNESS IS PRE-CONFIGURED FOR USE WITH AN MX-5 SPECIAL EDITION MAZDASPEED (FACTORY TURBO). BELOW ARE THE JUMPER SETTINGS REQUIRED FOR ITS USE WITH THE OTHER SUPPORTED MX-5 MODELS.

UNSCREW THE FRONT PLATE AND SLIDE OUT THE PCB TO ACCESS JUMPERS.

DEFAULT CONFIGURATION



MX-5 SPECIAL EDITION (FACTORY TURBO)



JUMPERS REQUIRED
B
D
F
H
J

ALTERNATE CONFIGURATION

MX-5 VCT





JUMPERS REQUIRED
B
D
H
I
L

 ID JUMPER

ALTERNATE CONFIGURATION

MX-5 NON-VCT



JUMPERS REQUIRED
B
D
H

 ID JUMPER

Immobiliser Light

NOTE: THIS PLUG 'N' PLAY PRODUCT DOES NOT SUPPORT THE FACTORY IMMOBILISER. YOU MAY NOTICE THE LIGHT IN THE INSTRUMENT CLUSTER FLASHING, THIS IS NORMAL AND WILL NOT AFFECT VEHICLE PERFORMANCE.

ECU Location

THE FACTORY MAZDA MX-5 ECU IS LOCATED UNDER A PROTECTIVE PLATE ON THE PASSENGER SIDE FOOT WELL. REMOVING THIS PANEL WILL ALLOW FOR THE INSTALLATION OF THIS HALTECH PLUG 'N' PLAY PRODUCT. THE FACTORY PROTECTIVE PLATE CAN BE RE-INSTALLED AFTER FITMENT OF HALTECH PRODUCTS.



Figure 1 - Haltech Installation



Figure 2 - Factory protective plate covering Haltech products

Air Temperature Sensor

An air temperature sensor is a required sensor used in Volumetric Efficiency (VE) tuning to compensate for changes in air density due to air temperature. Cold air has a higher density than warm air and therefore requires a greater volume of fuel to maintain the same air/fuel ratio.

The Haltech ECU can automatically compensate the fuel delivery for changes in air density based on temperature using the signal received from the air temperature sensor.

On many vehicles the OEM air temperature sensor is located either within the mass airflow sensor or molded into the intake air manifold, however in performance applications the airflow sensor and air intake piping are often modified, removed or replaced. For this reason an air temperature sensor (HT-010200) is provided for use as a substitute to the factory air temperature sensor.


This sensor should be mounted to provide the best representation of the actual temperature of the air entering the combustion chamber, i.e. after any turbocharger, supercharger and intercooler.

The sensor needs to be in the moving air stream to give fast response times and reduce heat soak effects. Be aware in some situations, mounting the sensor into the inlet manifold (especially at the rear) may cause heat soak problems (where the sensor reads the temperature of the manifold itself rather than the air that is moving through the manifold into the engine).

Once a suitable position has been located for the air temperature sensor to be installed, a hole should be drilled and tapped to accept the sensor. The intake manifold or inlet piping should be removed from the engine before this is done to prevent any metal shavings or swarf entering the engine.

This package includes an air temperature sensor (HT-010200). This air temperature sensor should be installed by utilising an auxiliary Analogue Voltage Input (AVI) and signal ground located on the 16 pin auxiliary connector.


Please refer to the auxiliary connector pinout table and sensor wiring diagram below.



INSERT WIRE THROUGH PLUG, THEN CRIMP THE PIN INTO THE WIRE AND DRAW BACK TO LOCK

Figure 3 - Air Temperature Sensor wiring

Auxiliary Connector




**AUXILIARY CONNECTOR (16 PIN)
REAR VIEW (WIRE SIDE)**

An auxiliary connector allows easy connection of additional ECU inputs and outputs.
Please see pinout information below for spare inputs and outputs available to this application.


Position (16 Pin Plug)	Connection	Function	Notes
1	From Haltech ECU (A9)	+5V	+5V Supply for Input Sensors (50mA Max)
2	From Haltech ECU (A2)	AVI 4	Spare Analogue Voltage Input
3	From Mazda Pin 3720	ADDITIONAL I/O	Fuel Tank Level Input
4	From Haltech ECU (B14, B15, B16)	SIGNAL GROUND	Signal Ground For Input Sensors
5	Not Used	-	-
6	Not Used	-	-
7	From Haltech ECU (B8)	SPI 1	Spare SPI (Optional Flex Fuel Input)
8	From Haltech ECU (A26)	+12V (INJ)	+12V Supply for Relays and Solenoids (500mA Max)
9	From Haltech ECU (A9)	+5V	+5V Supply for Input Sensors (50mA Max)
10	From Haltech ECU (B23)	CAN H	CAN High Connection from ECU
11	From Haltech ECU (B24)	CAN L	CAN Low Connection from ECU
12	From Haltech ECU (B14, B15, B16)	SIGNAL GROUND	Signal Ground For Input Sensors
13	Not Used	-	-
14	Not Used	-	-
15	From Haltech ECU (B7)	SPI 4	Spare Synchronised Pulsed Input
16	From Haltech ECU (A26)	+12V (INJ)	+12V Supply for Relays and Solenoids (500mA Max)

Main Connectors



CONNECTOR (32 PIN)
REAR VIEW (WIRE SIDE)

Position (32 Pin Plug)	ECU Connector (34 Pin Plug)	Function	Description
1	A1	DPO 2	A/C Control Relay
2	A2	AVI 4	Spare Analogue Voltage Input
3	A3	IGN 1	Ignition Coils 1 & 4
4	A4	IGN 2	Ignition Coils 2 & 3
5	A5	IGN 3	Thermofan
6	A6	IGN 4	VTCS Solenoid
7	Not Used	-	-
8	Not Used	-	-
9	A9	+5V	+5V DC Sensor Supply
10	A10	BATTERY GROUND	Battery Negative
11	A11	BATTERY GROUND	Battery Negative
12	A12	+8V	Not Used
13	A13	IGNITION INPUT	Ignition Switch
14	A14	AVI 10	Throttle Position Sensor
15	A15	AVI 9	Manifold Pressure Signal
16	A16	AVI 2	Power Steering Switch
17	A17	AVI 3	A/C Request
18	A18	DPO 1	Tachometer
19	A19	INJ 1	Injector #1
20	A20	INJ 2	Injector #2
21	A21	INJ 3	Injector #3
22	A22	INJ 4	Injector #4
23	A23	DPO 3	Idle Control Motor (BAC)
24	A24	DPO 5	Fuel Pump Relay
25	A25	DPO 6	Not Used
26	A26	+12V (INJ)	Fused Power
27	Not Used	-	-
28	Not Used	-	-
29	A31	STEP1 P1	Check Engine Light
30	A32	STEP2 P2	Wastegate Solenoid (Turbo Model Only) / Spare Output
31	A33	STEP3 P3	VCT Solenoid Control
32	A34	STEP4 P4	Alternator Control



CONNECTOR (24 PIN)
REAR VIEW (WIRE SIDE)

Position (24 Pin Plug)	ECU Connector (34 Pin Plug)	Function	Description
1	B1	TRIGGER	Crankshaft Position Sensor
2	B2	HOME	Camsahft Position Sensor
3	B3	AVI 7	Air Temperature Sensor
4	B4	AVI 8	Coolant Temperature Sensor
5	B5	TRIGGER -	Not Used
6	B6	HOME -	Not Used
7	B7	SPI 4	Spare Synchronsed Pulsed Input
8	B8	SPI 1	Spare SPI (Optional Flex Fuel Input)
9	B9	SPI 2	Vehicle Speed Sensor
10	B10	SPI 3	Clutch Switch
11	B11	+12V (ECU)	Fused Power
12	B12	AVI 6	Brake Switch
13	B13	AVI 1	O2 Sensor
14	B14	SIGNAL GROUND	Signal Ground For Input Sensors
15	B15	SIGNAL GROUND	Signal Ground For Input Sensors
16	B16	SIGNAL GROUND	Signal Ground For Input Sensors
17	B23	CAN HIGH	Not Used
18	B24	CAN LOW	Not Used
19	B19	DPO 4	Condensor Fan
20	B20	AVI 5	Mass Air Flow Signal
21	B21	KNOCK 1	Knock Sensor Signal
22	B22	KNOCK 2	Not Used
23	B25	DBW 1	Purge Control Solenoid (EVAP)
24	B26	DBW 2	Battery Light

WARNING - HALTECH OFF-ROAD USAGE POLICY

It is unlawful to tamper with your vehicle's emissions equipment.

Haltech products are designed and sold for sanctioned off-road/competition non-emissions controlled vehicles only. Using Haltech products for street/road use on public roads is prohibited by law. It is the responsibility of the installer and/or user of this product to ensure compliance with all applicable local and federal laws and regulations. Please check with your local vehicle authority before using any Haltech product

INSTALLATION OF HALTECH PRODUCTS

No responsibility whatsoever is accepted by Haltech for the fitment of Haltech Products. The onus is clearly on the installer to ensure that both their knowledge and the parts selected are correct for that particular application. Any damage to parts or consequential damage or costs resulting from the incorrect installation of Haltech products are totally the responsibility of the installer.

Always disconnect the battery when doing electrical work on your vehicle. Avoid sparks, open flames or use of electrical devices near flammable substances. Do not run the engine with a battery charger connected as this could damage the ECU and other electrical equipment. Do not overcharge the battery or reverse the polarity of the battery or any charging unit. Disconnect the Haltech ECU from the electrical system whenever doing any welding on the vehicle by unplugging the wiring harness connector from the ECU. After completing the ECU installation, make sure there is no wiring left uninsulated. Uninsulated wiring can cause sparks, short circuits and in some cases fire. Before attempting to run the engine ensure there are no leaks in the fuel system. All fuel system components and wiring should be mounted away from heat sources, shielded if necessary and well ventilated. Always ensure that you follow workshop safety procedures. If you're working underneath a jacked-up car, always use safety stands!

HALTECH LIMITED WARRANTY

Unless specified otherwise, Haltech warrants its products to be free from defects in material or workmanship for a period of 12 months from the date of purchase, valid in the original country of purchase only. Proof of purchase, in the form of a bill of sale or receipted invoice, which indicates that the product is within the warranty period, must be presented to obtain warranty service. Haltech suggests that the purchaser retain the dealer's dated bill of sale/receipt as evidence of the date of retail purchase. If the Haltech product is found to be defective as mentioned above, it will be replaced or repaired if returned prepaid along with proof of purchase. This shall constitute the sole liability of Haltech. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representations, either expressed or implied, including any implied warranty of merchantability or fitness. In no event shall Haltech be liable for special or consequential damages.

PRODUCT RETURNS

Please include a copy of the original purchase invoice along with the unused, undamaged product and its original packaging. Any product returned with missing accessory items or packaging will incur extra charges to return the item to a re-saleable condition. All product returns must be sent via a freight method with adequate tracking, insurance and proof of delivery services. Haltech will not be held responsible for product returns lost during transit. The sale of any sensor or accessory that is supplied in sealed packaging is strictly non-refundable if the sealed packaging has been opened or tampered with. This will be clearly noted on the product packaging. If you do not accept these terms please return the sensor in its original unopened packaging within 30 days for a full refund.

Returning a sensor or accessory product within 30 days of purchase: Product may be returned for credit or full refund. (Any sealed packaging must not have been opened or tampered with)

Returning a sensor or accessory product after 30 days of purchase: Product may be returned for credit only (no refunds given) and is subject to a 10% Restocking fee. (Any sealed packaging must not have been opened or tampered with)

V2.2

Need more help?



AUS: +61 2 9729 0999 **USA East:** (888) 298 8116 **USA West:** (949) 490 5660
Europe: +43 720 883968 **UK:** 0121 285 6650 **NZ:** 09 887 0616



www.haltech.com/support



support@haltech.com