


INSTALLATION MANUAL

Universal Electric Brake Vacuum Pump PFEVPUP28

<u>WARNING</u>: PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. PROFLOW WILL NOT BE RESPONSIBLE FOR ANY DAMAGE AS A RESULT OF THE INCORRECT INSTALLATION OF THIS PRODUCT. IT IS RECOMMENDED THAT A QUALIFIED AUTOMOTIVE TECHNICIAN PERFORMS THIS INSTALLATION.

WIRING DIAGRAM



* Please note pigtail has two red wires, please follow black wire from other side of plug to continue as negative in diagram

